

ALPHA-NUMERIC MEMORY LABEL STANDARD by KF4KIR

Purpose: frequencies alone have no relationship to location. Need to know where the repeater is with respect to current travel, usually mobile. Six characters is easy to text message via cell to another person to quickly establish radio communications.

VHF Repeater

Typically, 5 characters displayed

[last 3 of freq] [space] [2 letters of town]

Example: 135 RO 147.135 in Rockledge (K4EOC)

UHF Repeater

Typically, 6 characters

[last 3 of freq] [2 letters of town][4 for 440]

Example: 525RO4 444.525 in Rockledge (K4EOC)

1.25M (220 MHz) Repeater

Typically, 6 characters

[last 3 of freq] [2 letters of town][2 for 220]

Example: 120CO2 224.120 in Cocoa

OTHER

TAC x = Simplex, VHF

TAC y4 = Simplex, UHF

TACz4E = Simplex, UHF, DCS Encoded

M_CH: Marine Channel *Example: M_CH16*